



Maintenance

Lubrication Points	4-2
Maintenance Schedule	4-4





Lubrication Points

For the details of lubrication points and types of lubricants to be applied, refer to the illustrated index and various work procedures (such as Assembly/Reassembly, Replacement, Overhaul, Installation, etc.) contained in each section.

No.	LUBRICATION POINTS	LUBRICANT
1	Engine	API Service Grade: Use "Energy Conserving II" SG grade oil 5 W-30 preferred SAE Viscosity: See chart below.
2	Transmission Manual Automatic	API Service Grade: SF or SG SAE Viscosity: 10 W-30 or 10 W-40 Honda Premium Formula Automatic Transmission Fluid or an equivalent DEXRON® II Automatic Transmission Fluid (ATF)
3	Brake Line	Brake fluid DOT3 or DOT4
4	Clutch Line	Brake fluid DOT3 or DOT4
5	Power steering gearbox	Steering grease P/N 08733-BC70E
6	Shift lever pivots (Manual transmission)	Grease with molybdenum disulfide
7	Release fork (Manual transmission)	
8	Steering boots	
9	Throttle cable and	
10	Steering ball joints	
11	Select lever (Automatic transmission)	
12	Pedal linkage	
13	Intermediate shaft	
14	Brake master cylinder pushrod	
15	Trunk hinges	
16	Door hinges upper and lower	
17	Door opening detents	
18	Fuel fill lid	
19	Engine hood hinges and engine hood latch	
20	Clutch master cylinder pushrod	
21	Brake pipe joint (Front and rear wheel house)	Rust preventives
22	Caliper Caliper pin, Piston	Silicone grease
23	Power steering system	Honda power steering fluid-V
24	Differential	Hypoid gear Oil GL4 or GL5 Viscosity: at above -18°C (0°F): SAE 90 at less than -18°C (0°F): SAE 80 W 90

Recommended Engine Oil
API Service Grade: Use "Energy Conserving II"
SG grade oil 5 W-30 preferred



Service at the interval listed x 1,000 miles (or km) or after that number of months, whichever comes first.

- : Check oil and coolant level at each fuel stop.

* 1: For cars sold in California, this service is recommended only; other areas, it is required

• : Check oil and coolant level at each fuel stop.
 □ : Under severe driving conditions, service these items more often.

R—Replace I—Inspect After inspection, clean, adjust, repair or replace if necessary.

* : Check oil and coolant level at each fuel stop.

*1: The cars sold in California, this service is recommended only; other areas, it is required

☐ Under severe driving conditions, service these items more often.

*2: Thereafter, replace every 2 years or 30,000 miles (48,000 km), whichever comes first.

*3: This service is recommended only.



R—Replace I—Inspect After inspection, clean, adjust, repair or replace if necessary.

Service at the interval listed x 1,000 miles (or km) or after that number of months, whichever comes first.																NOTE	SEC and PAGE
	x 1,000 miles	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105		
	x 1,000 km	12	24	36	48	60	72	84	96	108	120	132	144	156	168		
Maintenance item	months	6	12	18	24	30	36	42	48	54	60	66	72	78	84		
Brakes																	
Anti-lock brake system operation																Function test Wheel sensor signal confirmation Anti-lock brake system indicator light	19-3
Anti-lock brake system high pressure hose																	
																Bleed high pressure fluid	19-71
Steering, Suspension, Miscellaneous																	
Front wheel alignment																Check rack grease and steering linkage. Check the boot for damage or leaking grease.	18-4
Steering operation, tie rod ends, steering gearbox and boots																	
<input type="checkbox"/> Power steering system																6.5–9.0 mm (0.26–0.35 in) @ 100 N (10 kg, 22 lbs) tension	17-20
Power steering pump belt																	
Suspension mounting bolts																Check tightness of bolts.	17-17
Supplemental restraint system																Inspect system 10 years after production	18-8, 22
Under severe driving conditions, service these items more often.																	

☐ Under severe driving conditions, service these items more often.

Severe Driving Conditions
Items with an **R** or **I** need service more often if you drive in some severe conditions.

- A: Repeated short distance driving
B: Dusty conditions
C: Severe cold weather
D: Areas with road salt or other corrosive materials
E: Rough or muddy roads
F: Towing a trailer

- Services for Severe Driving Conditions
- Clean the air cleaner element every 15,000 miles (24,000 km) or 12 months and replace every 30,000 miles (48,000 km) or 24 months under condition B or E.
 - Replace engine oil and oil filter every 3,750 miles (6,000 km) or 3 months under condition A, B or F.
 - Replace transmission oil every 15,000 miles (24,000 km) or 12 months under condition F.
 - Replace front differential oil every 15,000 miles (24,000 km) or 12 months under condition F.
 - Inspect front brake discs and calipers, and rear brake discs, calipers and pads every 7,500 miles (12,000 km) or 6 months under condition A, B, D, E or F.
 - Inspect the power steering system every 7,500 miles (12,000 km) or 6 months under condition B, C or E.

